



Connector Description

1. Golden Finger

- Pin 1: 12Vdc
- Pin 2: GND
- Pin 3: UART(RS-232) RxD, connect to UPS.
- Pin 4: UART(RS-232) TxD, connect to UPS.
- Pin 5: NC
- Pin 6: NC
- Pin 7: GND
- Pin 8: NC
- Pin 9: GND
- Pin 10: GND
- Pin 11: UART(RS-232) DTR
- Pin 12: UART(RS-232) DSR
- Pin 13: GPIO(General Purpose Input / Output)
- Pin 14: GPIO(General Purpose Input / Output)
- Pin 15: GPIO(General Purpose Input / Output)
- Pin 16: GPIO(General Purpose Input / Output)

J2: Modem or console port

Pin	Signal Name	Type
1	Not used	--
2	Receive (Rx)	In
3	Transmit (Tx)	Out
4	Data Terminal Ready	Out
5	Signal Ground (GND)	Power
6	Data Set Ready (DSR)	In
7	Not used	
8	Not used	

J1: 10/100BaseT RJ-45 Phone Jack

D2: Power / Network Tx/Rx LEDs